



COATING and FINISHING SYSTEM SELECTION

Any of the Following

ROCKCOTE

Step 1	Step 2	Step 3	Step 4
ROCKCOTE PATCH & PREP & ROCKCOTE MESH (Trowel or Spatula)	ROCKCOTE KEYCOTE (Trowel)	ROCKCOTE ACRYLIC TEXTURE COARSE/MEDIUM/SMOOTH (Trowel)	ROCKCOTE ARMOUR LOW SHEEN X 2 COATS (Roller or as per supplier's specifications)
ROCKCOTE SMOOTH SET & MESH TO JOINTS (Trowel)	SMOOTH SET X 1 COAT (Trowel)	ROCKCOTE ECOSTYLE SEALER/UNDERCOAT (Brush or roller or as per supplier's specifications)	ECOSTYLE LOW SHEEN X 2 COATS (Brush or roller or as per supplier's specifications)
ROCKCOTE PATCH & PREP & ROCKCOTE MESH (Trowel or Spatula)	ROCKCOTE KEYCOTE (Trowel)	ROCKCOTE TEXPRIME (Trowel)	ROCKCOTE SANDCOTE (Roller or as per supplier's specifications)

TAUBMANS – EXTERIOR

Step 1	Step 2	Step 3	Step 4
RENDER FINISH – TAUBMANS PREPRIGHT TRADITIONAL UNDERCOAT (D862) (Brush or Roller)	ARMAWALL POLYMER RENDER (D0238) (Brush or Roller)	ARMAWALL ARMASHEILD (D0245) (Brush or Roller)	ARMAWALL ARMASHEILD (D0245) (Brush or Roller)
PAINT FINISH – TAUBMANS PREPRIGHT TRADITIONAL UNDERCOAT (D862) (Brush or Roller)	ARMAWALL ARMASHEILD (D0245) (Brush or Roller)	ARMAWALL ARMASHEILD (D0245) (Brush or Roller)	

TAUBMANS – INTERIOR

PAINT FINISH – TAUBMANS PREPRIGHT TRADITIONAL UNDERCOAT (D862) (Brush or Roller)	TAUBMANS ENDURE INTERIOR LOW SHEEN (D172) (Brush or Roller)	TAUBMANS ENDURE INTERIOR LOW SHEEN (D172) (Brush or Roller)	
--	---	---	--

*** DISCLAIMER – ResCom waives all responsibility regarding their party materials and advises the consumer to seek confirmation from the supplier/manufacturer of those materials as to the suitability for use in the proposed application.**